

Getting Started for Connect Wireless Stick

NOTE

A complete user manual is available online at http://kb.sandisk.com/app/answers/detail/a_id/17367

1

Plug the SanDisk Connect™ Wireless Stick into a computer or USB-AC adapter to ensure that it's fully charged. A full charge can take up to 2 hours. Device cannot be connected using a USB cable.

2

Download and install the SanDisk Connect app on your mobile device. SanDisk® has many apps available, so please ensure you select the correct application, matching the icon image shown here.




Apps are available for iOS, Android and Kindle devices




3

Turn on the Connect Wireless Stick



LED status indicators



Device on	White blinking
WiFi data transfer	White rapid blinking
Battery charging	Amber solid
Low battery warning	Red blinking
Firmware update	Color cycling

4

Connect to Wireless Stick Wi-Fi network:

“SanDisk Connect #####”

*unique identifier
for your specific unit*

iPhone, iPad or iPod touch

Connect to the Wireless Stick Wi-Fi network through the device settings:
Click on the Settings icon > Click on Wi-Fi > Select “SanDisk Connect #####”

Android™ devices

Skip to Step 5. You will select your Wireless Stick Wi-Fi network through the app.

PC

Connect to the Wireless Stick Wi-Fi network through the PC network settings.

5

Launch the mobile app. On a PC/Mac, use a web browser and go to: www.sandisk.com/myconnect

NOTE

SanDisk continuously improves our user experience with bug fixes and enhancements. The SanDisk Connect mobile app may notify you that a new firmware is available. The app will also provide any instructions to update firmware. It is always recommended to update to the latest firmware version.